

coverdrive™

HOWTO – Clearing Learned Resonance Positions

This HOWTO explains how to clear previously saved learned resonance positions from the coverdrive Magnetic Loop Antenna Controller.

Step 1 – Open the Menu

From the main operating screen, open the controller menu.

Step 2 – Select Clear Positions

Select:

MENU-->CLEAR POS

Step 3 – Wait for Confirmation

The display will show:

POS CLEARED

PTS: 0

Step 4 – Resume Operation

The controller will continue operating normally using RC1.1 tracking until new resonance positions are added again.

Operational Notes

- CLEAR POS removes only learned resonance positions for the current band.
- Band setup and RC1.1 tracking information remain unchanged.
- New resonance positions can be added again at any time using MENU-->SAVE POS.
- Clearing positions may be useful when rebuilding or improving a resonance map.



coverdrive Magnetic Loop Antenna Controller

Document: HOWTO – Clearing Learned Resonance Positions

Purpose: Basic CLEAR POS Workflow